


P1699 TWICE OVERTRIAL

COMPONENT LOCATION



GENERAL DESCRIPTION

This is a special function for engine start by vehicle manufacturer. The engine can be started for moving from the production line to an area where the key teaching is proceeded.



DTC DESCRIPTION

The ECM sets DTC P1697 if the maximum limit of Twice IGN is Exceeded.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy		• Twice IGN \geq 32 times
Enable Conditions	• IG ON	
Threshold value		
Diagnostic Time		
Fail Safe		

SCHEMATIC DIAGRAM



MONITOR DTC STATUS

- 1). Connect scantool to Data Link Connector(DLC).
- 2). Ignition "ON" & engine "OFF".
- 3). Selet "Diagnostic Trouble Codes(DTCs)"mode and monitor "DTC Status" parameter
- 4). Is the DTC B1699 present?

YES

Go to "Inspection & Repair" procedure.

NO

Fault is intermittent caused by poor contact in SMARTRA's and/or ECM's connector or was repaired and ECMmemory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

- 1). Check communication between ECM and scantool.
 - A) IGN "ON" & Engine "OFF".
 - B) Connect scantool to Data Link Connector(DLC).
 - C) Erase the DTC and Monitor the "ECU STATUS" Parameter on the Scantool.

1.1 CURRENT DATA	
01. NO. OF LEARNT KEY	1
02. ECU STATUS	LEARNT
03. KEY STATUS	LEARNT

FIX
SCRN
FULL
PART
GRPH
HELP

Fig 1

Fig 1) The current data in abnormal state

D) Is "ECU STATUS" Parameter "Locked"?

YES

Keep "KEY ON" status for 1 hour to withdraw "Locked by Timer" status. Then register transponder and go to "Verification of Vehicle Repair" procedure.

NO

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

- 1). Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2). Operate the vehicle and monitor the DTC on the scantool.
- 3). Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.