# B1115, B1116 SATELLITE SENS RH

# Description

Main "G" sensor generates signal voltage, when it detects deceleration beyond the specified level by vehicle side collision.

#### OPERATION

When air bag diagnosis sensor unit define the both signal voltage of the "G" sensor and the Safing algorithm to be that of collision which exceeds specified level, the driving circuit switches on and feeds the electric ignitor of both the side air bag and curtain air bag.

## STRUCTURE

Integrated type of the "G" sensor element for side collision with output terminals for signal voltage.

#### INSTALLATION

RH satellite sensor is installed at the underside of center pillar with fixed nuts.

# DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
B1115 B1116	SATELLITE SENS RH [COMM FAIL] [UNMATCH]	RH satellite sensor is out of order	Disconnection of wiring harness     Internal breakdown in RH satellite sensor     Internal breakdown in air bag diagnosis sensor unit

### DTC CONFIRMATION PROCEDURE

- INSPECTION START Turn ignition switch ON.
- 2).CHECK SELF-DIAG RESULT
  - A). Check the screen of CONSULT-III.
  - B).Is malfunctioning part detected?
    YES >> Refer to SRC-97, "Diagnosis Procedure".
    NO >> INSPECTION END.
- 3).INSPECTION START Turn ignition switch ON.
- 4). CHECK AIR BAG WARNING LAMP
  - A). Check the air bag warning lamp status.
  - B).Is malfunctioning part detected?

    YES >> Refer to warning lamp flash code chart.

    NO >> INSPECTION END.

# Diagnosis Procedure

- 1). CHECK HARNESS CONNECTOR
  - A). Check the connection of harness connector.
  - B).Is the inspection result normal? YES >> GO TO 2.

NO >> Repair or replace harness connectors.

- 2).CHECK WIRING HARNESS
  - A). Check the wiring harness externals.
  - B).Is the inspection result normal? YES >> GO TO 3.

NO >> Repair or replace wiring harness.

- 3).CHECK SATELLITE SENSOR
  - A).Replace RH satellite sensor.
  - B).Check the screen of CONSULT-III.
  - C).Is the inspection result normal?

YES >> INSPECTION END.

NO >> Check the intermittent incident.