## Discussion on Matching Iran Peugeot 206 Air Bag

Launch Software Peugeot Engineer Cao Ziteng

Here we discuss how to match Peugeot 206 air bag system with X431.

After users choose the value of match option, users can do matching, that is, the operation is just rewriting information to ECU.

Now we introduce the procedure as following:


fig.1-3

Click 206/Air bags/SAC-CENT-AUTOLIV-2 to select option needs to match.


Select function test				Configuration			
System ident:	ification						
Read trouble	code						
Clear trouble	e code		prior configuration, check which pre-				
Configuration	n		tensioning co vehicle. The tensioning co fitted on the continuous li warning light	tensioning components are fitted on the vehicle. The configuration of a pretensioning component which is not fitted on the vehicle results in continuous lighting of the fault warning light, while the ECU may indicate No faults.			
PAGE UP		PAGE DOWN					
HOME	BACK PRI	NT HELP		OIK			
Start [	□ .	À: ₩ 15:14	Start ) 🗇	₩ %	EEE 16:48		
	1-1	l unit)		g.1-2	l unit)		
Pre-tensioning	,	- A 20	Pre-tensioning seat belt YES				
Driver's air bag YES				Driver's air bag YES			
Passenger air bag YES				Passenger air bag			
Disaming switch YES				Disarming switch			
Front side air bags YES			Front side ai	Front side air bags YES			
Side airbags s	screens 1	NO	Side airbags	Side airbags screens NO			
		33					
PAGE UP	PAGE DOWN	PRINT	PAGE UP	PAGE DOWN	PRINI		
Modify	Program	BACK	Modify	Program	BACK		
Start ) [	<b>□</b> 3	£ 16:49	Start ) 🗓	<b>P</b> 3	£=17:28		


Click fig. 1-3, press OK key, and then the screen will display the menu as shown in fig.1-3. It shows the initial value of ECU. Users can do match according to the configuration of air bag. For example, the initial value of Pre-tensioning seat belt is YES which is not included in configuration of vehicle. See fig.1-4. Click Modify, and then select the option needs to match. See fig.1-5 & fig. 1-6.

Conf	iguration	(control u	nit)			
Pre-tensio	ning seat	belt				
Driver's	river's air bag					
Passenger	air bag					
Disarming	switch					
Front side	air bags					
Side airba	gs screen:	3	72			
			2.0			
PAGE UP		PAGE DOWN				
HOME	BACK	PRINT	HELP			
Start		<b>₽</b> ☆	₩¥ 17:28			
	fig.1-5					



Now, users can click Program to write information to ECU.





Writing information to ECU needs to switch off the unit. See fig.1-8. Click OK to

enter the writing information menu again. See fig. 1-9.




fig.1-9

The operation is just to rewrite and re-read ECU. If the configuration is not match to actual condition, certain permanent fault code will occur till matching is correct. Then, the permanent fault code will turn to temporary fault code. Now, you can clear fault with clear fault code function.