

## DTC B2615

SIE-ID = 1967364 Owner = dmcgre01 LMD = 13-aug-2007 LMB = tdedvu01

### Diagnostic Instructions

- a) Perform the Diagnostic System Check – Vehicle on page 6-60 prior to using this diagnostic procedure.
- b) Review Strategy Based Diagnosis on page 6-57 for an overview of the diagnostic approach.
- c) Diagnostic Procedure Instructions on page 6-58 provides an overview of each diagnostic category.

### DTC Descriptor

**DTC B2615 00:** Passenger Compartment Dimming 2 Circuit

### Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
B+, BCM X4 Terminal 2	B2615 00	B2615 00	—	—
Courtesy Lamps Control	B2615 00	2	1	—
1. Courtesy Lamps Always On 2. Courtesy Lamps Inoperative				

### Circuit/System Description

Battery voltage for the courtesy lamps is supplied at all times, from the CTSY Fuse located in the I/P fuse block, to the body control module (BCM). When the BCM receives a signal to command the courtesy lamps ON, it then applies voltage through the courtesy lamps control circuits to the courtesy lamps listed below.

- a) Left and right footwell lamps
- b) Left and right liftgate lamps
- c) Courtesy/reading lamps
- d) Cargo lamp

## Conditions for Running the DTC

The BCM attempts to illuminate the courtesy lamps.

## Conditions for Setting the DTC

The BCM detects a short to ground on the courtesy lamp control circuit.

## Action Taken When the DTC Sets

The BCM will not attempt to activate courtesy lamps.

## Conditions for Clearing the DTC

A history DTC will clear once 100 consecutive malfunction ignition cycles have occurred.

## Circuit/System Verification

Ignition ON, command the Courtesy Lamps ON and OFF with a scan tool. The courtesy lamps should turn ON and OFF when changing between commanded states.

## Circuit/System Testing

- 1) Ignition OFF, disconnect the X4 harness connector at the BCM.
- 2) Verify that a test lamp illuminates between the B+ circuit terminal 2 and ground.

If the test lamp does not illuminate, test the B+ circuit for a short to ground or an open/high resistance. If the circuit tests normal and the B+ circuit fuse is open, test the control circuits listed below for a short to ground.

- a) Courtesy lamp control terminal 1 X6
- b) Courtesy lamp control terminal 5 X2
- 3) Ignition OFF, connect the X4 harness connector at the BCM.
- 4) Disconnect the harness connectors at all components fed by the control circuits listed below.
  - a) Courtesy lamp control terminal 1 X6
  - b) Courtesy lamp control terminal 5 X2

- 5) Ignition ON, clear the DTC with a scan tool.
- 6) Operate the vehicle within the conditions for running the DTC and verify the DTC does not reset.

If the DTC resets, test the control circuits for a short to ground. If the circuits test normal, replace the BCM.

- 7) Reconnect each component one at a time and verify that the DTC does not reset.

If the DTC resets, test or replace the component responsible for setting the DTC.

LAUNCH