

LAUNCH


BMW Teach In End Stop 318i 2011

Description:


BMW 318i, VIN: WBAP*****

Steps:

1. Enter BMW software and choose "Automatically Search".




2. After scanner read out vehicle info, click "Next".



LAUNCH

3. Read help info carefully, and click "OK" to continue.



4. Click "Health Report" to read out all DTC.



LAUNCH

5. After Clear DTCs, we can find 63F8 can't be clear.

Module	Count	Status
ECM (Engine Control Module - DME/DDE)	1	Normal
TCM (Transmission Control Module - EGS/DKG/SMG)	2	Normal
EPS (Electronic Power Steering)	1	Normal
CAS (Car Access System - CAS/FEM/BDC)		Normal
ABS (Anti-Lock Braking System - DSC)		Normal
SGM-ZGM (Safety And Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM)		Normal
SRS (Supplemental Inflatable Restraint System - AIRBAG/SGM-SIM)		Normal

BMW 318i 2011
VIN WBAPF710XCF103106

Report Help Compare Results Clear DTCs


Module	Count	Status
EPS (Electronic Power Steering)	1	Normal
<i>63F8 EPS: Software - End Stop Not Taught</i>		<i>History</i>
ECM (Engine Control Module - DME/DDE)		Normal
ABS (Anti-Lock Braking System - DSC)		Normal
SGM-ZGM (Safety And Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM)		Normal
SRS (Supplemental Inflatable Restraint System - AIRBAG/SGM-SIM)		Normal
TCU (Telematic Control Unit - TEL/ULF/ULF-SBX)		Normal
DWA (Anti-theft Alarm System)		Normal

BMW 318i 2011
VIN WBAPF710XCF103106



Report Help Compare Results Clear DTCs

LAUNCH

6. Enter "Special Function".




7. Choose "Chassis">> "EPS: Teach-in End Stop".




LAUNCH

8. Clicks continue.




9. Read the preparation carefully, and do as it say. Click continue.




LAUNCH

10. Turn steering wheel as the system info reminder.



11. Click No.



LAUNCH

12. Succeed.

