

B1553: CAN Communication Circuit Malfunction

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives error code from BCM continuously.	<ul style="list-style-type: none"> • CAN communication circuit • BCM • ECM • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check ECM and BCM for DTC. Is there DTC(s)?	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.