

B1563: A/C Refrigerant Pressure Signal Failure

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of A/C refrigerant pressure signal from BCM.	<ul style="list-style-type: none"> • A/C refrigerant pressure sensor circuit • A/C refrigerant pressure sensor • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in ECM. Is DTC P0532 or P0533 detected?	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.