

# TOYOTA Camry 2024 Remote Door Lock Setting

**Tested Model:** Toyota Camry 2024

## Function Description:


This function is used to set the remote door lock for Toyota models.

## Execution Conditions:


Engine/power switch ON (engine off/Ready indicator lamp off).

## Procedure:


1. On a PAD 5, choose [Local Diagnose] (as shown below).




2. Choose [TOYOTA] for testing (as shown below).




3. Click OK (as shown below).




- 4. Choose [16PIN DLC (North America)] to start identifying the model. You can choose [Set Area] to choose the region. In this test, choose the North America region (as shown below).




- 5. Choose [w/Smart Key] (as shown below).





6. Choose [w/EPB (Electrical Parking Brake)] (as shown below).




7. Click OK (as shown below).




8. Choose [TS (Telematics System)] and click [Enter] (as shown below).




9. Choose [Special Function] (as shown below).




10. Choose [Remote Door Lock Setting] (as shown below).




11. When setting the remote door lock, use this function. Click OK (as shown below).




12. Confirm the following conditions and click OK (as shown below).




13. Click OK (as shown below).




14. Choose the following options for setting. In this test, choose [Remote Door Lock Available] (as shown below).



15. Start setting. Please wait.



16. After the remote door lock setting is completed, click OK to exit the function.



## Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.