

# B1BBD OCM CURRENT CONFIGURATION TABLE UNPROGRAMMED

1). When Monitored:

If the Configuration Table is not programmed at the supplier or when the checksum is invalid.

2). Set Condition:

This DTC will set if the module was received unprogrammed from the supplier, the vehicle line was not identified correctly or if the flash procedure was not completed successfully.

Possible Causes
1. NEW OCCUPANT CLASSIFICATION MODULE
2. INTERNAL CHECKSUM FAILURE

## Diagnostic Test

1). MODULE CONFIGURATION

Does the scan tool display B1BBD-OCM CURRENT CONFIGURATION TABLE UNPROGRAMMED?

**Yes** >> Perform the B1BA7-OCS VERIFICATION REQUIRED diagnostic procedure.

**No** >> Replace the Occupant Classification Module in accordance with the service information.

With the scan tool, perform the OCM SYSTEM VERIFICATION procedure.