

## OPERATING GUIDE OF EUROFORD ODOMETER WRITE SYSTEM

This function is only necessary on newly installed instrument clusters.

The attention of the two points :

A.It is not possible to overwrite a value lower than the mileage.

B.If the odometer write failed, you can try again.

1.Diagnose: Select“Calling system”menu(See Figure 1).




Figure 1

Wait for 1 minutes. Then the Vehicles Specification screen displays.(See Figure 2)



Figure 2

2. Select "ICM" menu (See Figure 3) .




Figure 3

Enter Odometer Write functions in the "SPECIAL FUNCTION" menu (See Figure 4)




Figure 4

3. When selecting "Odometer Write", it will display as Figure5




Figure 5

It can only enter a value higher than actual mileage. (Now Mileage: 34531Miles)  
 (See Figure 6)




Figure 6

If you enter a value lower than actual mileage, it show: (See Figure 7)




Figure 7

Press ok to reenter (See Figure 8)




Figure 8

when you enter a correct data, it will show : (See Figure 9)




Figure 9

Press ok to Complete. (See Figure 10)




Figure 10