




I GROUND POINT





* 1 : w/ Automatic Glare-Resistant EC Mirror
 * 2 : w/ Moon Roof
 * 3 : w/o Moon Roof

I GROUND POINT



Relay Blocks

Code	Relay Blocks (Relay Block Location)
1	Engine Room R/B (Engine Compartment Left)
3	RH R/B (Right Side of the Instrument Panel Reinforcement)

Junction Block and Wire Harness Connector

Code	Junction Block and Wire Harness (Connector Location)
IE	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)()
IH _	
II _	
3A	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

Connector Joining Wire Harness and Wire Harness

Code	Joining Wire Harness and Wire Harness (Connector Location)
IA4	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)g ()
IA5 _	
IA6 _	
IC1	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IF1	Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Center)
IG1	Instrument Panel Wire and Instrument Panel No.3 Wire (Front Side of the Parking Brake Lever)
IH1	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)
II1	Engine Wire and Instrument Panel Wire (Blower Unit RH) Engine Wire and Instrument Panel Wire (Blower Unit RH)
II2 _	
IJ2	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

Ground Points

Code	Ground Points Location
EA	Front Right Fender
EB	Left Side of the Cylinder Head Left Side of the Cylinder Head
EC _	
ED	Front Left Suspension Tower
IE	Behind the Combination Meter Behind the Combination Meter
IF _	
IG	Right Kick Panel
BH	Under the Left Quarter Pillar
BI	Lower Back Panel
BJ	Under the Right Quarter Pillar

Splice Points

Code	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	Engine Room Main Wire	B1	4444	Roof Wire Roof Wire
E2_38	B2			
E4	Engine Room Main Wire	B3	44	Front Door RH Wire
I8	Instrument Panel Wire	B4	44	Front Door LH Wire