

# Instructions for Service Reset

## [Tested Model]


Range Rover (L460)2023, VIN: SALKABFU3PA04\*\*\*\*

## [Function Execution Background]



When the vehicle requires the reset of engine oil, inspection, and service information, execute this function.



## [Procedure]

1. Turn on the vehicle ignition switch, connect Launch X431 PAD 7 connector, and select the Land Rover model software (V34.85 or later). After entering, choose [Automatically Search].







- In the [Operator Information] dialog box, choose [YES] to use online mode for the diagnosis. After entering the interface, choose [Use DoIP Protocol for Vehicle Communication]. After a successful login, choose [Special Function] > [Common Special Function] > [Reset].







3. Click [Service Message Reset]. A prompt appears stating the battery voltage > 12.0V. If you select [NO], it will prompt that the corresponding voltage is required, and click OK to return to the previous menu (the Service Message Reset page). If you select [YES], it will prompt you to turn on the ignition switch, and click OK to proceed to the next step.





4. The Service Message Reset Menu is displayed. If you click [Back], you will return to the interface at the start of Step 3 (the Service Message Reset page). If you click [Full Service Reset], a prompt appears indicating that the operation is successful. Click OK to return to the interface at the start of Step 3 (the Service Message Reset page).



## [Statement]

The content of this document is copyrighted by Shenzhen Launch Tech Co., Ltd., and no individual or organization may quote or reprint it without consent.