


## Programming the units for the trip computer

This function is intended to set the trip computer unit.


Now we take S40(04-) 2008 30786352 AD (ECU Diagnostic Part Number) as an example to illustrate the operation:

Note: The highlight item in the figure indicates corresponding action.




1. step 1: S40(04-)



2. step 2: select year






3. step 3: select DIM

SELECT MENU			
DIM(Driver information module)			
PDM(Passenger door module)			
PSM(Power seat module)			
DDM(Driver door module)			
CCM(Climatè control module)			
PHM(Phone module)			
SWM(Steering wheel module)			
AUD(Audio Module)			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 10:27

4. step 4:




Select: Special Function.

If you can't find the Special Function menu, it means the function has not been developed on your vehicle. Please record the VIN (Vehicle Identification Number) and Version Information (can be read by X431 with the function: Reading off control module ID) and email to Launch (x431@cnlaunch.com). We may work out a solution on how to solve the problem.

Select function			
Reading off control module ID			
Reading off Diagnostic Trouble Codes			
Erasing Diagnostic Trouble Codes			
Parameter display			
Activating components/functions			
Service Reset			
Special Function			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 10:28

5. step 5:

Select: Programming the units for the trip computer

Please select special function item			
Programming the units for the trip computer			
Programming parking brake warning			
Programming the audible acknowledgement signal, seat belt reminder			
Programming instrument lighting			
Programming text message, seatbelt reminder			
Read out programmed values			
Display of DSTC message			
PAGE UP		PAGE DOWN	
HOME	BACK	PRINT	HELP
Start			 16:16

## 6. step 6:

The information of Programming the units for the trip computer:

Ignition on





The units for the trip computer unit can be set if you have purchased this function

The following units can be selected:

- Liters
- GB Gallon
- US Gallon
- km/l

Read off the parameter that is programmed.

To change the unit, marking the required unit in the list and start programming.





Note information	
<p>-Ignition on The units for the trip computer unit can be set if you have purchased this function. The following units can be selected: -Liters -GB Gallon -US Gallon -km/l Read off the parameter that is programmed. To change the unit, marking the required unit in the list and start programming.</p>	
OK	CANCEL
Start     16:17	

LAUNCH





## 7. step 7:

Select Ok then it will send command to ECU, and display information like this:

Note! If not support information displayed, it will exit this function.

Note information	
Not Supported	
OK	PRINT
<span>Start</span>     14:41	

If support, display information like this:

ACTUATION TEST				
Programmed Value		Litre		
F1: Tripcomputer, unit = Liter				
F2: Tripcomputer, unit = GB Gallon				
F3: Tripcomputer, unit = US Gallon				
F4: Tripcomputer, unit = km/l				
PAGE UP		PAGE DOWN		PRINT
<	F1	F2	F3	F4 >
<span>Start</span>     16:18				

The first line, Programmed Value Liter, is the present programmed value for your vehicle, if you want to change this value, you can select the desired value in the list:

- F1: Trip computer, unit = Liter
- F2: Trip computer, unit = GB Gallon
- F3: Trip computer, unit = US Gallon
- F4: Trip computer, unit = km/l

For example: if you want to change this value to km/l, please select F4 and it will start programming. When programming finish, the Programmed Value will change to km/l as the following figure, it means that the programming succeeds.

Note! Maybe some vehicles can not be programmed. (Programmed Value does not change when programming)

ACTUATION TEST				
Programmed Value		km/l		
F1: Tripcomputer, unit = Liter				
F2: Tripcomputer, unit = GB Gallon				
F3: Tripcomputer, unit = US Gallon				
F4: Tripcomputer, unit = km/l				
PAGE UP		PAGE DOWN		PRINT
<	F1	F2	F3	F4 >
Start				16:20

8. step 8:

When you want to exit this programming, please select EXIT:

ACTUATION TEST				
Programmed Value		km/l		
F1: Tripcomputer, unit = Liter				
F2: Tripcomputer, unit = GB Gallon				
F3: Tripcomputer, unit = US Gallon				
F4: Tripcomputer, unit = km/l				
PAGE UP		PAGE DOWN		PRINT
<	F2	F3	F4	<b>EXIT</b> >
Start				16:22