

# GM Chevrolet Blazer Backup Battery Timer Reset


**Supported equipment:** Launch's full range of comprehensive diagnostic equipment

**Current equipment:** PAD V


**Function description:** This function is used to reset the backup battery timer.

**Tested model:** 2020 Chevrolet Blazer VIN: 3GNKBJR45LS6\*\*\*\*\*

1. It is necessary to stop the vehicle before performing this function. On a PAD V, choose [Local Diagnose].



2. Then, choose [GM] to test.



### GM Diagnose V49.70

#### INTRODUCTION

This diagnostic software can test the ECUs of GM Models, including:

Engine Control Module, Transmission Control Module, Antilock Braking System, Supplemental Inflatable Restraint, Body Control Module, Instrument Panel Cluster, Heating and Air Conditioning, Tire Pressure Monitor, Electronic Suspension Control, Radio, Driver Door Module, Driver Position Module, Passenger Door Module, Remote Control Door Lock Receiver, Vehicle Comm. Interface Module, Immobilizer, Amplifier and so on.

#### Basic Functions:



- Reading ECU information
- Reading DTCs
- Clearing DTCs
- Reading vehicle running data
- Vehicle component operation test


#### Special Functions:

- Engine Control Module:
  - Oil Life Reset
  - Accelerator Pedal Position (APP) Learn





3. Choose [Automatically Search] to identify car models automatically.






4. Click [Smart Detection] to scan the entire vehicle systems.








5. Click [TCICM (Telematics Communication Interface Control Module)] to access the system.




6. Click [Special Functions] and then click [Remove/Reset Module].



7. Choose [Backup Battery Timer Reset].



8. Click [Reset].



9. The status changes from “None” to “Reset”.

The screenshot shows a mobile application interface for 'Backup Battery Timer Reset'. The title bar is blue with the text 'Backup Battery Timer Reset' and navigation icons. Below the title bar, there is a status bar with the text 'GM V49.70 > Automatically Search > Telematics Communication Interface Control Module (TCICM)' and network/Bluetooth icons. The main content area is a table with three columns: 'Parameter Name', 'Status', and 'Unit'. The first row has 'Commanded State' in the 'Parameter Name' column, 'Reset' in the 'Status' column, and an empty cell in the 'Unit' column. Below the table, there are two buttons: 'Reset' and 'Release Control'. At the bottom, there is a grey bar with the text 'Blazer 2020' and 'VIN 3GNKBJR45LS6'. The bottom of the screen shows a standard Android navigation bar.

| Parameter Name  | Status | Unit |
|-----------------|--------|------|
| Commanded State | Reset  |      |

Reset Release Control

Blazer 2020  
VIN 3GNKBJR45LS6

## Statement:

The content of this document is copyrighted by Shenzhen Launch Tech Co., Ltd., and no individual or organization may quote or reprint it without consent.