

FIAT Tonale Exit Logistic Mode


Supported equipment: Launch's full range of comprehensive diagnostic equipment


Current equipment: PAD 5

Function description: When it is necessary to deactivate the logistic mode and enable normal functions for FIAT vehicles, this program is executed.

Tested model: 2022/Fiat/Tonale, VIN: ZARNASBA4N30*****

1. On a PAD 5, choose [Local Diagnose] and then [FIAT] to test.





FIAT V38.75

Introduction

ECU Coverage:

This Software Diagnoses All FIAT Series ECUs, Including Engine, AT, ABS, SRS, A/C, Instrument, Power Steering, Body PC, Door Control, Tire Pressure Control, Parking Control And Headlamp, Etc.

(The Following Models Covered Are Only For Reference And Will Vary Constantly With The Upgrades Of Software.)

Basic Functions Include:



- Reading ECU Information
- Reading DTCs
- Clearing DTCs
- Reading Vehicle Running Data
- Vehicle component Operation Test

Special functions include:


- Key Programming([Body Module])
- Tire Pressure detection([Body Module]/[Tire Pressure Control])
- Reset Adaption




2. Choose [Automatically Search] to identify car models automatically. After the car model is successfully identified, choose OK.




3. Choose [Yes] to unlock the SGW.




4. Choose [North America] for the region.




5. Input the login user name and password, and click OK.




6. Unlocking is successful. Click OK.




7. Click [Smart Detection] to scan the entire vehicle systems.




8. Click [BCM (Body Control Module)] to access the system.




9. Choose [Special Function].




10. Choose [Misc Function].




11. Choose [Exit Logistic Mode].




12. Click OK.




13. Click OK.




14. Click [Continue].




15. Click OK.




16. Click OK.



17. Click OK.



18. Click OK. Program execution is completed.



Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.