

# Ford Transit Brake System Pressure Bleeding


**Supported equipment:** Launch's full range of comprehensive diagnostic equipment

**Current equipment:** PAD 5



**Function description:** This function needs to be performed when bleeding the brake system.

**Tested model:** Ford/2023/Transit, VIN: WF0EXXTTREPJ\*\*\*\*\*



1. On a PAD 5, choose [Local Diagnose].




## 2. Choose [FORD] to test.




3. Choose [Automatically Search] to identify car models automatically.








4. Click [High-speed Scan] to scan the entire vehicle systems.




5. Click [ABS (Anti-Lock Brake System)] to access the system.




## 6. Click [Special Functions].




## 7. Click [Brake System Pressure Bleeding].




## 8. Ignition status: Ignition on, engine off




## 9. Check the warning items and operate according to the prompts.



10. Wait for the program to execute.




11. Close the FL bleed screw.







12. Wait for 45s.



13. Ignition status: Ignition off



14. The program is completed. Exit the program.



## Statement:

The content of this document is copyrighted by LAUNCH TECH CO., LTD., and no individual or organization may quote or reprint it without consent.